Term
Baseline
Definition: An initial set of observations or data used for comparison or as a control; a starting point.
Beneficial uses
Definition: See Designated uses. Preferred Term: Designated use
Best management practice
Definition: A method that has been determined to be the most effective, practical means of preventing or reducing pollution from
nonpoint sources.
Acronym: BMP
Biocriteria
Definition: The biological characteristics that quantitatively describe a waterbody with a healthy community of fish and associated
aquatic organisms. Components of biocriteria include the presence and seasonality of key indicator species; the abundance, diversity, and structure of the aquatic community; and the habitat conditions required for these organisms.
Calibration
Definition: Testing and tuning of a model to a set of field data not used in developing the model; also includes minimization of
deviations between measured field conditions and output of a model by selecting appropriate model coefficients.
Clinger richness

Term
Definition: A metric used to measure the diversity of macroinvertebrates that have the ability to attach to the substrate in flowing water.
Coefficient of skewness
Definition: Most commonly used measure of skewness. It is influenced by the presence of outliers because it is calculated using the mean and standard deviation.
Acronym: g
Combined sewer overflow
Definition: Overflow from systems designed to collect runoff, domestic sewage, and industrial wastewater in the same pipe system.
Acronym: CSO
Criteria
Definition: Standards that define minimum conditions, pollutant limits, goals, and other requirements that the waterbody must attain or maintain to support its designated use or uses. Criteria describe physical, chemical, and biological attributes or conditions as measurable (e.g., parts per million of a certain chemical) or narrative (e.g., no objectionable odors) water quality components.
CWA section 303(d)
Definition: Section of the Clean Water Act under which states, territories, and authorized tribes are required to develop lists of impaired waters.
CWA section 305(b)

Term
Definition: Section of the Clean Water Act under which states are required to prepare a report describing the status of their water quality every 2 years.
CWA section 319
Definition: Section of the Clean Water Act under which EPA has developed guidelines to help states, territories, and tribes implement nonpoint source pollutant management programs and provide grants to fund the programs.
Delineation
Definition: The process of identifying a watershed boundary on the basis of topographic information. Designated use
Definition: Simple narrative description of water quality expectations or water quality goals. A designated use is a legally recognized description of a desired use of the waterbody, such as (1) support of communities of aquatic life, (2) body contact recreation, (3) fish consumption, and (4) public drinking water supply. These are uses that the state or authorized tribe wants the waterbody to be healthy enough to fully support. The Clean Water Act requires that waterbodies attain or maintain the water quality needed to support designated uses.
Discounting
Definition: The process of calculating the present value of a project on the basis of the current value of the projected stream of costs throughout the project's lifetime. Eutrophication

Term
Definition: Enrichment of an aquatic ecosystem with nutrients (nitrogen, phosphorus) that accelerate biological productivity (growth of algae and weeds) and an undesirable accumulation of algal biomass.
First-order decay
Definition: A reaction in which the concentration decreases exponentially over time.
Geographic information system
Definition: A tool that links spatial features commonly seen on maps with information from various sources ranging from demographics to pollutant sources. Acronym: GIS
Hydrologic unit code
Definition: A unique code, consisting of two to eight digits (based on the four levels of classification in the hydrologic unit system), that identifies each hydrologic unit. Acronym: HUC
Impaired waterbody
Definition: A waterbody that does not meet the criteria that support its designated use.
Indicator
Definition: Direct or indirect measurements of some valued component or quality in a system. Can be used to measure the current health of the watershed and to provide a way to measure progress toward meeting the watershed goals.

Term
Information/education (I/E) activities
Definition: Public outreach.
Interquartile range
Definition: The difference between the 25th and 75th percentile of the data. Because the IQR measures the range of the central 50 percent of the data and is not influenced by the 25 percent on either end, it is less sensitive to extremes or outliers than the sample variance and standard deviation. Acronym: IQR
Management measure
Definition: A group of cost-effective practices implemented cooperatively to achieve more comprehensive goals, such as reducing the loads of sediment form a field to receiving waters.
Management practice
Definition: A method that is effective and practical for preventing or reducing pollution from nonpoint sources. Management practices, which are the building blocks of management measures, are similar to best management practices.
Maximum (statistics)
Definition: The highest data value recorded during the period of record.
McNeil core

Term
Definition: A streambed sample collected with a McNeil core sampler and used to characterize the composition of the substrate.
Mean
Definition: The sum of all data values divided by the number of samples. The mean is strongly influenced by "outlier" samples
(extremely high or low samples), with one outlier sample possibly shifting the mean significantly higher or lower.
Measure of central tendency
Definition: Measure that identifies the general center of a dataset.
Measure of range
Definition: Measure that identifies the span of the data from low to high.
Measure of skewness
Definition: Measure that shows whether a dataset is asymmetrical around the mean or median and suggests how much the
distribution of the data differs from a normal distribution.
Measure of spread
Definition: Measure of the variability of the dataset.
Median (P0.50)
Definition: The 50th percentile data point; the central value of the dataset when ranked in order of magnitude. The median is more

Term
resistant to outliers than the mean and is only minimally affected by single observations.
Mesotrophic
Definition: Describes reservoirs and lakes that contain moderate quantities of nutrients and are moderately productive in terms of
aquatic animal and plant life.
Minimum (statistics)
Definition: The lowest data value recorded during the period of record.
Model
Definition: A representation of an environmental system obtained through the use of mathematical equations or relationships.
Model application
Definition. The use of a model or models to address defined questions at a specific leastion
Definition: The use of a model or models to address defined questions at a specific location.
Modeling system
Definition: A computer program or software package that incorporates a model and input and output systems to facilitate application.
Narrative criteria
Definition: Nonnumeric descriptions of desirable or undesirable water quality conditions.
National Pollutant Discharge Elimination System

## Term

Definition: A provision of the Clean Water Act that prohibits the discharge of pollutants into waters of the United States unless a special permit is issued by EPA, a state, or, where delegated, a tribal government on an Indian reservation. Acronym: NPDES

Nine minimum elements

Definition: Components that EPA has identified as critical for achieving improvements in water quality. EPA requires that these nine elements be addressed for section 319 funded watershed plans and strongly recommends they be included in all watershed plans that are intended to remediate water quality impairments.

Nonpoint source

Definition: Diffuse pollution source; a source without a single point of origin or not introduced into a receiving stream from a specific outlet. The pollutants are generally carried off the land by stormwater. Common nonpoint sources are agriculture, forestry, urban areas, mining, construction, dams, channels, land disposal, saltwater intrusion, and city streets.

Nonstructural practice

Definition: A practice that prevents or reduces runoff problems in receiving waters by reducing the generation of pollutants and managing runoff at the source. This type of practice may be included in a regulation or may involve voluntary pollution prevention practices.

Numeric criteria

Definition: Criteria or limits for many common pollutants that are based on laboratory and other studies that test or otherwise examine

Term
the effects of pollutants on live organisms of different species.
Point source
Definition: A stationary location or fixed facility from which pollutants are discharged; any single identifiable source of pollution, such
as a pipe, ditch, ship, ore pit, or factory smokestack.
Pollutant
Definition: A contaminant in a concentration or amount that adversely alters the physical, chemical, or biological properties of the
natural environment.
Pollutant load
Definition: The amount of pollutants entering a waterbody. Loads are usually expressed in terms of a weight and a time frame, such
as pounds per day (lb/d).
Probabilistic sampling
Definition: Sampling in which sites are randomly chosen to represent a larger sampling population for the purpose of trying to answer
broad-scale (e.g., watershed-wide) questions.
Quality assurance project plan
Definition: A project-specific document that specifies the data quality and quantity requirements of a study, as well as the procedures
that will be used to collect, analyze, and report the data.
Acronym: QAPP

Term
Quartile skew coefficient
Definition: Measure of the difference in the distances of the upper and lower quartiles (upper and lower 25 percent of data) from the median. The qs is more resistant to outliers because, like the IQR, it uses the central 50 percent of the data. Acronym: qs
Reach file
Definition: A series of national hydrologic databases that uniquely identify and interconnect the stream segments or "reaches" that compose the country's surface water drainage system.
Remote sensing
Definition: The collection of data and information about the physical world by detecting and measuring radiation, particles, and fields associated with objects located beyond the immediate vicinity of the sensor device(s).
Sample variance (s2) and its square root standard deviation (s)
Definition: The most common measures of the spread (dispersion) of a set of data. These statistics are computed using the squares of the difference between each data value and the mean, so that outliers influence their magnitudes dramatically. In datasets with major outliers, the variance and standard deviation might suggest much greater spread than exists for the majority of the data.
Sanitary sewer overflow
Definition: An occasional unintentional discharge of raw sewage from a municipal sanitary sewer. Acronym: SSO

Term
SCS curve number
Definition: Number used to determine runoff, as a result of rainfall, for a specific land area based on the area's hydrologic condition, land use, soil, and treatment.
Stakeholder
Definition: Individual or organization that has a stake in the outcome of the watershed plan.
Structural practice
Definition: A practice, such as a stormwater basin or streambank fence, that requires construction, installation, and maintenance.
Targeted sampling
Definition: Sampling in which sites are allocated to specific locations of concern (e.g., below discharges, in areas of particular land use, at stream junctions to isolate subwatersheds) for the purpose of trying to answer site-specific questions.
Threatened waterbody
Definition: A waterbody that is meeting standards but exhibits a declining trend in water quality such that it will likely exceed standards.
Total Maximum Daily Load
Definition: The amount, or load, of a specific pollutant that a waterbody can assimilate and still meet the water quality standard for its

Term
designated use. For impaired waters the TMDL reduces the overall load by allocating the load among current pollutant loads (from point and nonpoint sources), background or natural loads, a margin of safety, and sometimes an allocation for future growth. Acronym: TMDL
Universal Soil Loss Equation
Definition: An equation used to predict the average rate of erosion of an area on the basis of the rainfall, soil type, topography, and management measures of the area. Acronym: USLE
Validation
Definition: Subsequent testing of a precalibrated model to additional field data, usually under different external conditions, to further examine the model's ability to predict future conditions. Same as verification.
Verification
Water quality standards
Definition: Standards that set the goals, pollution limits, and protection requirements for each waterbody. These standards are composed of designated (beneficial) uses, numeric and narrative criteria, and antidegradation policies and procedures.
Watershed
Definition: Land area that drains to a common waterway, such as a stream, lake, estuary, wetland, or ultimately the ocean.

Term

Watershed approach

Definition: A flexible framework for managing water resource quality and quantity within specified drainage area, or watershed. This approach includes stakeholder involvement and management actions supported by sound science and appropriate technology. Watershed plan

Definition: A document that provides assessment and management information for a geographically defined watershed, including the analyses, actions, participants, and resources related to development and implementation of the plan.