

Terminology Services - Vocabulary Catalog List Detail Report

Term
<p>1,1,1-Trichloroethane</p> <p>Definition: Please see the ATSDR fact sheet for 1,1,1-TCA.</p> <p>Acronym: 1,1,1-TCA</p>
<p>1,1-Dichloroethane</p> <p>Definition: Please see the ATSDR fact sheet for 1,1-DCA.</p> <p>Acronym: 1,1-DCA</p>
<p>1,1 Dichloroethylene or 1,1 Dichloroethene</p> <p>Definition: Please see the ATSDR fact sheet for 1,1 Dichloroethylene or 1,1 Dichloroethene.</p>
<p>Administrative Order on Consent</p> <p>Definition: A legal agreement signed by EPA and an individual, business, or other entity through which the violator agrees to pay for correction of violations, take the required corrective or cleanup actions, or refrain from an activity. It describes the actions to be taken, may be subject to a comment period, applies to civil actions, and can be enforced in court.</p>
<p>Aeration</p> <p>Definition: A process which promotes biological degradation of organic matter in water. The process may be passive (as when waste is exposed to air), or active (as when a mixing or bubbling device introduces the air).</p>
<p>Aerobic Treatment</p>

Terminology Services - Vocabulary Catalog List Detail Report

Term
Definition: Process by which microbes decompose complex organic compounds in the presence of oxygen and use the liberated energy for reproduction and growth. (Such processes include extended aeration, trickling filtration, and rotating biological contactors.)
Affected Public
Definition 1: 1. The people who live and/or work near a hazardous waste site. Definition 2: 2. The human population adversely impacted following exposure to a toxic pollutant in food, water, air, or soil.
Agency for Toxic Substances and Disease Registry
Definition: Agency for Toxic Substances and Disease Registry (ATSDR) is charged under the Superfund Act to assess the presence and nature of health hazards at specific Superfund sites, to help prevent or reduce further exposure and the illnesses that result from such exposures, and to expand the knowledge base about health effects from exposure to hazardous substances.
Acronym: ATSDR
Air Sparging
Definition: Injecting air or oxygen into groundwater to strip or flush volatile contaminants up through the groundwater as air bubbles and capture them with a vapor extraction system.
Air Stripping
Definition: A treatment system that removes volatile organic compounds (VOCs) from contaminated ground water or surface water by forcing an airstream through the water and causing the compounds to evaporate.
Alluvial

Terminology Services - Vocabulary Catalog List Detail Report

Term
<p>Definition: Relating to and/or sand deposited by flowing water.</p> <p>Aqueous</p>
<p>Definition: Something made up of water.</p> <p>Aquifer</p>
<p>Definition: An underground geological formation, or group of formations, containing water. Are sources of groundwater for wells and springs.</p> <p>Arsenic</p>
<p>Definition: Please see the ATSDR fact sheet for arsenic.</p> <p>Attenuation</p>
<p>Definition: The process by which a compound is reduced in concentration over time, through absorption, adsorption, degradation, dilution, and/or transformation. an also be the decrease with distance of sight caused by attenuation of light by particulate pollution.</p> <p>Background Level</p>
<p>Definition 1: 1. The concentration of a substance in an environmental media (air, water, or soil) that occurs naturally or is not the result of human activities. Definition 2: 2. In exposure assessment the concentration of a substance in a defined control area, during a fixed period of time before, during, or after a data-gathering operation.</p> <p>Benzene</p>

Terminology Services - Vocabulary Catalog List Detail Report

Term
Definition: Please see the ATSDR fact sheet for benzene.
Bioremediation
Definition: Use of living organisms to clean up oil spills or remove other pollutants from soil, water, or wastewater; use of organisms such as non-harmful insects to remove agricultural pests or counteract diseases of trees, plants, and garden soil.
Brownfields
Definition: Abandoned, idled, or under used industrial and commercial facilities/sites where expansion or redevelopment is complicated by real or perceived environmental contamination. They can be in urban, suburban, or rural areas. EPA's Brownfields initiative helps communities mitigate potential health risks and restore the economic viability of such areas or properties.
Cap
Definition: A layer of clay, or other impermeable material installed over the top of a closed landfill to prevent entry of rainwater and minimize leachate.
Carcinogen
Definition: Any substance that can cause or aggravate cancer.
Chlorinated Solvent
Definition: An organic solvent containing chlorine atoms(e.g., methylene chloride and 1,1,1-trichloromethane). Uses of chlorinated

Terminology Services - Vocabulary Catalog List Detail Report

Term
solvents are include aerosol spray containers, in highway paint, and dry cleaning fluids.
Chromated Copper Arsenate
Definition: A water-borne preservative containing active ingredients that are inorganic metal oxides, or less frequently salts, and are commonly used to treat dimensional lumber and telephone poles.
Chromium
Definition: Please see the ATSDR fact sheet for chromium.
Cleanup
Definition: Actions taken to deal with a release or threat of release of a hazardous substance that could affect humans and/or the environment. The term "cleanup" is sometimes used interchangeably with the terms remedial action, removal action, response action, or corrective action.
Combustion
Definition 1: 1. Burning, or rapid oxidation, accompanied by release of energy in the form of heat and light. Definition 2: 2. Refers to controlled burning of waste, in which heat chemically alters organic compounds, converting into stable inorganics such as carbon dioxide and water
Comment Period
Definition: Time provided for the public to review and comment on a proposed EPA action or rulemaking after publication in the Federal Register.

Terminology Services - Vocabulary Catalog List Detail Report

Term
<p>Composting</p> <p>Definition: The controlled biological decomposition of organic material in the presence of air to form a humus-like material. Controlled methods of composting include mechanical mixing and aerating, ventilating the materials by dropping them through a vertical series of aerated chambers, or placing the compost in piles out in the open air and mixing it or turning it periodically.</p>
<p>Consent Decree (Order)</p> <p>Definition: A legal document, approved by a judge, that formalizes an agreement reached between EPA and potentially responsible parties (PRPs) through which PRPs will conduct all or part of a cleanup action at a Superfund site; cease or correct actions or processes that are polluting the environment; or otherwise comply with EPA initiated regulatory enforcement actions to resolve the contamination at the Superfund site involved. The consent decree describes the actions PRPs will take and may be subject to a public comment period.</p>
<p>Constituent(s) of Concern</p> <p>Definition: Specific chemicals that are identified for evaluation in the site assessment process.</p>
<p>Contaminant</p> <p>Definition: Any physical, chemical, biological, or radiological substance or matter that has an adverse effect on air, water, or soil.</p>
<p>Corrective Action</p> <p>Definition: EPA can require treatment, storage and disposal (TSDF) facilities handling hazardous waste to undertake corrective actions to clean up spills resulting from failure to follow hazardous waste management procedures or other mistakes. The process</p>

Terminology Services - Vocabulary Catalog List Detail Report

Term
includes cleanup procedures designed to guide TSDFs toward in spills.
Corrective Measures Study
Definition: A step in the RCRA Subtitle C corrective action process when the owner and operator identifies and evaluates remediation alternatives at a given contaminated site.
Creosote
Definition: Please see the ATSDR fact sheet for creosote.
Dense Non-Aqueous Phase Liquid
Definition: Non-aqueous phase liquids such as chlorinated hydrocarbon solvents or petroleum fractions with a specific gravity greater than 1.0 that sink through the water column until they reach a confining layer. Because they are at the bottom of aquifers instead of floating on the water table, typical monitoring wells do not indicate their presence. Acronym: DNAPL
Designer Bugs
Definition: Popular term for microbes developed through biotechnology that can degrade specific toxic chemicals at their source in toxic waste dumps or in ground water.
Dioxin
Definition: Any of a family of compounds known chemically as dibenzo-p-dioxins. Concern about them arises from their potential toxicity as contaminants in commercial products. Tests on laboratory animals indicate that it is one of the more toxic anthropogenic

Terminology Services - Vocabulary Catalog List Detail Report

Term
(man-made) compounds.
Dioxins/Furans
Definition: Please see the ATSDR fact sheet for dioxins/furans.
Disposal
Definition: Final placement or destruction of toxic, radioactive, or other wastes; surplus or banned pesticides or other chemicals; polluted soils; and drums containing hazardous materials from removal actions or accidental releases. Disposal may be accomplished through use of approved secure landfills, surface impoundments, land farming, deep-well injection, ocean dumping, or incineration.
Downgradient
Definition: The direction that groundwater flows; similar to "downstream" for surface water.
Ecological Risk Assessment
Definition: The application of a formal framework, analytical process, or model to estimate the effects of human actions(s) on a natural resource and to interpret the significance of those effects in light of the uncertainties identified in each component of the assessment process. Such analysis includes initial hazard identification, exposure and dose-response assessments, and risk characterization.
Engineered Controls
Definition: Method of managing environmental and health risks by placing a barrier between the contamination and the rest of the

Terminology Services - Vocabulary Catalog List Detail Report

Term
site, thus limiting exposure pathways.
Environmental Indicator
Definition: A measurement, statistic or value that provides a proximate gauge or evidence of the effects of environmental management programs or of the state or condition of the environment.
Environmental Justice
Definition: The fair treatment and meaningful involvement of all people--regardless of race, color, national origin, or income--in the development, implementation, and enforcement of environmental laws, regulations, and policies. Acronym: EJ
Environmental Site Assessment
Definition: The process of determining whether contamination is present on a parcel of real property.
Exposure Pathway
Definition: The path from sources of pollutants via, soil, water, or food to man and other species or settings.
Flocculation
Definition: Process by which clumps of solids in water or sewage aggregate through biological or chemical action so they can be separated from water or sewage.
Flue Gas

Terminology Services - Vocabulary Catalog List Detail Report

Term
<p>Definition: The air coming out of a chimney after combustion in the burner it is venting. It can include nitrogen oxides, carbon oxides, water vapor, sulfur oxides, particles and many chemical pollutants.</p>
<p>Fly Ash</p>
<p>Definition: Non-combustible residual particles expelled by flue gas.</p>
<p>Generator</p>
<p>Definition: A facility or mobile source that emits pollutants into the air or releases hazardous waste into water or soil.</p>
<p>Ground Water</p>
<p>Definition: The supply of fresh water found beneath the Earth's surface, usually in aquifers, which supply wells and springs. Because ground water is a major source of drinking water, there is growing concern over contamination from leaching agricultural or industrial pollutants or leaking underground storage tanks.</p>
<p>Hazardous Waste</p>
<p>Definition: By-products of society that can pose a substantial or potential hazard to human health or the environment when improperly managed. Possesses at least one of four characteristics (ignitability, corrosivity, reactivity, or toxicity), or appears on special EPA lists.</p>
<p>Hazardous Waste Landfill</p>

Terminology Services - Vocabulary Catalog List Detail Report

Term
Definition: An excavated or engineered site where hazardous waste is deposited and covered.
Hazardous Waste Management Unit
Acronym: HWMU
Heavy Metals
Definition: Metallic elements with high atomic weights; (e.g., mercury, chromium, cadmium, arsenic, and lead); can damage living things at low concentrations and tend to accumulate in the food chain.
Human Health Risk
Definition: The likelihood that a given exposure or series of exposures may have damaged or will damage the health of individuals.
Hydrocarbons
Definition: Chemical compounds that consist entirely of carbon and hydrogen.
Acronym: HC
Imminent Hazard
Definition: One that would likely result in unreasonable adverse effects on humans or the environment or risk unreasonable hazard to an endangered species during the time required for a pesticide registration cancellation proceeding.
Impermeable

Terminology Services - Vocabulary Catalog List Detail Report

Term
<p>Definition: Not easily penetrated. The property of a material or soil that does not allow, or allows only with great difficulty, the movement or passage of water.</p>
<p>Impoundment</p>
<p>Definition: A body of water or sludge confined by a dam, dike, floodgate, or other barrier.</p>
<p>Incineration</p>
<p>Definition: A treatment technology involving destruction of waste by controlled burning at high temperatures; e.g., burning sludge to remove the water and reduce the remaining residues to a safe, non-burnable ash that can be disposed of safely on land, in some waters, or in underground locations.</p>
<p>Industrial Process Waste</p>
<p>Definition: Residues produced during manufacturing operations.</p>
<p>Industrial Sludge</p>
<p>Definition: Semi-liquid residue or slurry remaining from treatment of industrial water and wastewater.</p>
<p>Interim (Permit) Status</p>
<p>Definition: Period during which treatment, storage and disposal facilities coming under RCRA in 1980 are temporarily permitted to operate while awaiting a permanent permit. Permits issued under these circumstances are usually called "Part A" or "Part B" permits.</p>

Terminology Services - Vocabulary Catalog List Detail Report

Term
Lagoon
Definition: A shallow pond where sunlight, bacterial action, and oxygen work to purify wastewater; also used for storage of wastewater or spent nuclear fuel rods.
Land Disposal Restrictions
Definition: Rules that require hazardous wastes to be treated before disposal on land to destroy or immobilize hazardous constituents that might migrate into soil and ground water.
Land Farming (of Waste)
Definition: A disposal process in which hazardous waste deposited on or in the soil is degraded naturally by microbes.
Large Quantity Generator
Definition: Person or facility generating more than 2200 pounds of hazardous waste per month. Such generators produce about 90 percent of the nation's hazardous waste, and are subject to all RCRA requirements.
Leachate
Definition: Water that collects contaminants as it trickles through wastes, pesticides or fertilizers. Leaching may occur in farming areas, feedlots, and landfills, and may result in hazardous substances entering surface water, ground water, or soil.
Lift

Terminology Services - Vocabulary Catalog List Detail Report

Term
Definition: In a sanitary landfill, a compacted layer of solid waste and the top layer of cover material.
Light Non-Aqueous Phase Liquid
Definition: A non-aqueous phase liquid with a specific gravity less than 1.0. Because the specific gravity of water is 1.0, most LNAPLs float on top of the water table. Most common petroleum hydrocarbon fuels and lubricating oils are LNAPLs.
Acronym: LNAPL
Liner
Definition: A relatively impermeable barrier designed to keep leachate inside a landfill. Liner materials include plastic and dense clay.
Mechanical Aeration
Definition: Use of mechanical energy to inject air into water to cause a waste stream to absorb oxygen.
Media
Definition: Specific environments--air, water, soil--which are the subject of regulatory concern and activities.
Mercury
Definition: Heavy metal that can accumulate in the environment and is highly toxic if breathed or swallowed.
Acronym: Hg
Mining Waste

Terminology Services - Vocabulary Catalog List Detail Report

Term
Definition: Residues resulting from the extraction of raw materials from the earth.
Mitigation
Definition: Measures taken to reduce adverse impacts on the environment.
Monitoring
Definition: Periodic or continuous surveillance or testing to determine the level of compliance with statutory requirements and/or pollutant levels in various media or in humans, plants, and animals.
Monitoring Well
Definition 1: 1. A well used to obtain water quality samples or measure groundwater levels. Definition 2: 2. A well drilled at a hazardous waste management facility or Superfund site to collect ground-water samples for the purpose of physical, chemical, or biological analysis to determine the amounts, types, and distribution of contaminants in the groundwater beneath the site.
Mulch
Definition: A layer of material (wood chips, straw, leaves, etc.) placed around plants to hold moisture, prevent weed growth, and enrich or sterilize the soil.
Multi-Media Approach
Definition: Joint approach to several environmental media, such as air, water, and land.
Necrosis

Terminology Services - Vocabulary Catalog List Detail Report

Term
<p>Definition: Death of plant or animal cells or tissues. In plants, necrosis can discolor stems or leaves or kill a plant entirely.</p>
<p>Neutralization</p>
<p>Definition: Decreasing the acidity or alkalinity of a substance by adding alkaline or acidic materials, respectively.</p>
<p>Nitrate</p>
<p>Definition: A compound containing nitrogen that can exist in the atmosphere or as a dissolved gas in water and which can have harmful effects on humans and animals. Nitrates in water can cause severe illness in infants and domestic animals. A plant nutrient and inorganic fertilizer, nitrate is found in septic systems, animal feed lots, agricultural fertilizers, manure, industrial waste waters, sanitary landfills, and garbage dumps.</p>
<p>Non-Aqueous Phase Liquid</p>
<p>Definition: Contaminants that remain undiluted as the original bulk liquid in the subsurface, e.g., spilled oil.</p>
<p>Acronym: NAPL</p>
<p>Off-Site Facility</p>
<p>Definition: A hazardous waste treatment, storage or disposal area that is located away from the generating site.</p>
<p>On-Site Facility</p>
<p>Definition: A hazardous waste treatment, storage or disposal area that is located on the generating site.</p>

Terminology Services - Vocabulary Catalog List Detail Report

Term
Organic
Definition 1: 1. Referring to or derived from living organisms. Definition 2: 2. In chemistry, any compound containing carbon.
Organic Matter
Definition: Carbonaceous waste contained in plant or animal matter and originating from domestic or industrial sources.
Osmosis
Definition: The passage of a liquid from a weak solution to a more concentrated solution across a semipermeable membrane that allows passage of the solvent (water) but not the dissolved solids.
Outfall
Definition: The place where effluent is discharged into receiving waters.
Oxidation Pond
Definition: A man-made (anthropogenic) body of water in which waste is consumed by bacteria, used most frequently with other waste-treatment processes; a sewage lagoon.
Particulates
Definition 1: 1. Fine liquid or solid particles such as dust, smoke, mist, fumes, or smog, found in air or emissions. Definition 2: 2. Very small solids suspended in water; they can vary in size, shape, density and electrical charge and can be gathered together by

Terminology Services - Vocabulary Catalog List Detail Report

Term
coagulation and flocculation.
Passive Treatment Walls
Definition: Technology in which a chemical reaction takes place when contaminated ground water comes in contact with a barrier such as limestone or a wall containing iron filings.
Pentachlorophenol
Definition: Please see the ATSDR fact sheet for Pentachlorophenol.
Perched Water
Definition: A zone of unpressurized water held above the water table by impermeable rock or sediment.
Percolation
Definition 1: 1. The movement of water downward and radially through subsurface soil layers, usually continuing downward to ground water. Can also involve upward movement of water. Definition 2: 2. Slow seepage of water through a filter.
Permeability
Definition: The rate at which liquids pass through soil or other materials in a specified direction.
Permit
Definition: An authorization, license, or equivalent control document issued by EPA or an approved state agency to implement the

Terminology Services - Vocabulary Catalog List Detail Report

Term
requirements of an environmental regulation; e.g., a permit to operate a wastewater treatment plant or to operate a facility that may generate harmful emissions.
Pesticide
Definition: Substances or mixture there of intended for preventing, destroying, repelling, or mitigating any pest. Also, any substance or mixture intended for use as a plant regulator, defoliant, or desiccant.
pH
Definition: An expression of the intensity of the basic or acid condition of a liquid; may range from 0 to 14, where 0 is the most acid and 7 is neutral. Natural waters usually have a pH between 6.5 and 8.5.
Phytotreatment
Definition: The cultivation of specialized plants that absorb specific contaminants from the soil through their roots or foliage. This reduces the concentration of contaminants in the soil, but incorporates them into biomasses that may be released back into the environment when the plant dies or is harvested.
Pilot Tests
Definition: Testing a cleanup technology under actual site conditions to identify potential problems prior to full-scale implementation.
Plugging
Definition: Act or process of stopping the flow of water, oil, or gas into or out of a formation through a borehole or well penetrating that formation.

Terminology Services - Vocabulary Catalog List Detail Report

Term
<p>Plume</p> <p>Definition: A visible or measurable discharge of a contaminant from a given point of origin. Can be visible or thermal in water, or visible in the air as, for example, a plume of smoke.</p>
<p>Point Source</p> <p>Definition: A stationary location or fixed facility from which pollutants are discharged; any single identifiable source of pollution; e.g., a pipe, ditch, ship, ore pit, factory smokestack</p>
<p>Pollutant</p> <p>Definition: Generally, any substance introduced into the environment that adversely affects the usefulness of a resource or the health of humans, animals, or ecosystems.</p>
<p>Polychlorinated Biphenyls</p> <p>Definition: Please see the ATSDR fact sheet for PCBs.</p> <p>Acronym: PCBs</p>
<p>Polycyclic Aromatic Hydrocarbons</p> <p>Definition: Please see the ATSDR fact sheet for polycyclic aromatic hydrocarbons.</p> <p>Acronym: PAHs</p>
<p>Post-Closure</p>

Terminology Services - Vocabulary Catalog List Detail Report

Term
<p>Definition: The time period following the shutdown of a waste management or manufacturing facility; for monitoring purposes, often considered to be 30 years.</p>
<p>Potentially Responsible Parties</p> <p>Definition: Potentially Responsible Parties (PRPs) are individuals, companies, or any other party that are potentially liable for payment of Superfund cleanup costs.</p> <p>Acronym: PRP</p>
<p>Preliminary Assessment</p> <p>Definition: The process of collecting and reviewing available information about a known or suspected waste site or release.</p>
<p>Proposed Plan</p> <p>Definition: A plan for a site cleanup that is available to the public for comment.</p>
<p>Public Comment Period</p> <p>Definition: The time allowed for the public to express its views and concerns regarding an action by EPA (e.g., a Federal Register Notice of proposed rule-making, a public notice of a draft permit, or a Notice of Intent to Deny).</p>
<p>Public Notice</p> <p>Definition: Notification by EPA informing the public of Agency actions such as the issuance of a draft permit or scheduling of a hearing. EPA is required to ensure proper public notice, including publication in newspapers and broadcast over radio and television stations.</p>

Terminology Services - Vocabulary Catalog List Detail Report

Term
<p>RCRA 3008 Order</p> <p>Definition: Order 3008(h) authorizes EPA to issue administrative (i.e., enforcement) orders or bring court action to require corrective action or other measures when there is or has been a release of hazardous waste or hazardous constituents from a RCRA facility operating under interim status.</p>
<p>RCRA Facility Assessment</p> <p>Definition: A step in the RCRA Subtitle C corrective action process where owners and operators compile existing information on environmental conditions at a given facility, including information on actual and potential releases.</p>
<p>RCRA Facility Investigation</p> <p>Definition: Site characterization used to ascertain the nature and extent of contamination of releases identified during a Subtitle C RCRA facility assessment or the Phase 1 RCRA facility investigation.</p> <p>Acronym: RFI</p>
<p>Release</p> <p>Definition: Any spilling, leaking, pumping, pouring, emitting, emptying, discharging, injecting, escaping, leaching, dumping, or disposing into the environment of a hazardous or toxic chemical or extremely hazardous substance.</p>
<p>Remedial Response</p> <p>Definition: Long-term action that stops or substantially reduces a release or threat of a release of hazardous substances that is serious but not an immediate threat to public health.</p>

Terminology Services - Vocabulary Catalog List Detail Report

Term
Remediation
Definition: Cleanup or other methods used to remove or contain a toxic spill or hazardous materials from a hazardous waste site.
Removal Action
Definition: Short-term immediate actions taken to address releases of hazardous substances that require expedited response. (See: cleanup.)
Resource Conservation and Recovery Act
Definition: The Resource Conservation and Recovery Act (RCRA) protects human health and the environment from the potential hazards of waste disposal, conserves energy and natural resources, reduces the amount of waste generated, and ensures that wastes are managed in an environmentally sound manner. Acronym: RCRA
Responsiveness Summary
Definition: A summary of oral and/or written public comments received by EPA during a comment period on key EPA documents, and EPA's response to those comments.
Retrofit
Definition: Addition of a pollution control device on an existing facility without making major changes to the generating plant. Also called backfit.
Risk Assessment

Terminology Services - Vocabulary Catalog List Detail Report

Term
<p>Definition: Qualitative and quantitative evaluation of the risk posed to human health and/or the environment by the actual or potential presence and/or use of specific pollutants.</p>
<p>Rotary Kiln Incinerator</p> <p>Definition: An incinerator with a rotating combustion chamber that keeps waste moving, thereby allowing it to vaporize for easier burning.</p>
<p>Seepage</p> <p>Definition: Percolation of water through the soil from unlined canals, ditches, laterals, watercourses, or water storage facilities.</p>
<p>Sink</p> <p>Definition: Place in the environment where a compound or material collects.</p>
<p>Sludge</p> <p>Definition: A semi-solid residue from any of a number of air or water treatment processes; can be a hazardous waste.</p>
<p>Small Quantity Generator</p> <p>Definition: Persons or enterprises that produce 220-2200 pounds per month of hazardous waste. The largest category of hazardous waste generators, SQGs, include automotive shops, dry cleaners, photographic developers, and many other small businesses. (See: conditionally exempt generators.)</p>

Terminology Services - Vocabulary Catalog List Detail Report

Term
Acronym: SQG
Solid Waste Management Unit
Definition: A discernible unit where solid or hazardous wastes have been placed at any time, or any area where solid wastes have been routinely and systematically released.
Sparge or Sparging
Definition: Injection of air below the water table to strip dissolved volatile organic compounds and/or oxygenate ground water to facilitate aerobic biodegradation of organic compounds.
Spoil
Definition: Dirt or rock removed from its original location--destroying the composition of the soil in the process--as in strip-mining, dredging, or construction.
Stakeholder
Definition: Any organization, governmental entity, or individual that has a stake in or may be impacted by a given approach to environmental regulation, pollution prevention, energy conservation, etc.
Storage
Definition: Temporary holding of waste pending treatment or disposal, as in containers, tanks, waste piles, and surface impoundments.

Terminology Services - Vocabulary Catalog List Detail Report

Term
Sump
Definition: A pit or tank that catches liquid runoff for drainage or disposal.
Surface Impoundment
Definition: Treatment, storage, or disposal of liquid hazardous wastes in ponds.
Surface Water
Definition: All water naturally open to the atmosphere (rivers, lakes, reservoirs, ponds, streams, impoundments, seas, estuaries, etc.)
Tailings
Definition: Residue of raw material or waste separated out during the processing of crops or mineral ores.
Tetrachloroethylene
Definition: Please see the ATSDR fact sheet for PERC. Acronym: PCE or PERC
Thermal Treatment
Definition: Use of elevated temperatures to treat hazardous wastes.(See: incineration; pyrolysis.)
Toluene

Terminology Services - Vocabulary Catalog List Detail Report

Term
Definition: Please see the ATSDR fact sheet for toluene.
Topography
Definition: The physical features of a surface area including relative elevations and the position of natural and man-made (anthropogenic) features.
Toxic Substance
Definition: A chemical or mixture that may present an unreasonable risk of injury to health or the environment.
Toxic Substances Control Act
Definition: Enables EPA to track the 75,000 industrial chemicals currently produced or imported into the U.S. EPA repeatedly screens these chemicals and can require reporting or testing of those that may pose an environmental or human-health hazard. EPA can ban the manufacture and import of those chemicals that pose an unreasonable risk. Acronym: TSCA
Toxicity
Definition: The degree to which a substance or mixture of substances can harm humans or animals. Acute toxicity involves harmful effects in an organism through a single or short-term exposure.
Toxics Release Inventory
Definition: A database that contains information concerning waste management activities and the release of toxic chemicals by facilities that manufacture, process, or otherwise use such materials. Citizens, businesses, and governments can then use this

Terminology Services - Vocabulary Catalog List Detail Report

Term
information to work together to protect the quality of their land, air, and water. Acronym: TRI
Trichloroethene Definition: Please see the ATSDR fact sheet for TCE. Acronym: TCE
Unconfined Aquifer Definition: An aquifer containing water that is not under pressure; the water level in a well is the same as the water table outside the well.
Underground Storage Tank System Definition: A tank and any underground piping connected to the tank that has at least 10 percent of its combined volume underground. Under the Resource Conservation and Recovery Act (RCRA), EPA has established regulatory programs to prevent, detect, and clean up releases from USTs containing petroleum or hazardous substances. Acronym: UST
Volatile Liquids Definition: Liquids which easily vaporize or evaporate at room temperature.
Volatile Organic Chemicals Definition: Any organic compound that participates in atmospheric photochemical reactions except those designated by EPA as

Terminology Services - Vocabulary Catalog List Detail Report

Term
having negligible photochemical reactivity. Acronym: VOCs
Volatile Solids
Definition: Those solids in water or other liquids that are lost on ignition of the dry solids at 550° centigrade.
Water Quality Criteria
Definition: Levels of water quality expected to render a body of water suitable for its designated use. Criteria are based on specific levels of pollutants that would make the water harmful if used for drinking, swimming, farming, fish production, or industrial processes.
Water Table
Definition: The level of ground water.
Watershed
Definition: The land area that drains into a stream; the watershed for a major river may encompass a number of smaller watersheds that ultimately combine at a common point.
Wood Treatment Facility
Definition: An industrial facility that treats lumber and other wood products for outdoor use. The process employs chromated copper arsenate, which is regulated as a hazardous material.
Xylene

Terminology Services - Vocabulary Catalog List Detail Report

Term
Definition: Please see the ATSDR fact sheet for xylene.